



Crunch Passion v.1.1 is dual guitar preamp (Clean & Crunch)

Clean section is a Clean Tube style model.

Drive Section is a Crunch drive. The sound is look like Laney model (but in here, I am not trying to model specific of any model in market). Drive section input depend to clean section.

Shape is for control the tone, if turn Right will be sharp and otherwise dull.

Bass – Mid – Hi are 10dB range per each. So (ex) Bass -5dB to 0 to 5dB

Volume is just the matter of controlling signal.

Default MIDI CC:

1. On Of Button
2. Clean Knob
3. CD Button
4. Drive Knob
5. Shape Knob
6. Bass Knob
7. Mid Knob
8. Hi Knob
9. Volume Knob

Note:

Avoid Peak as possible, from your signal input to output signal of the plugin and TRUST YOUR EAR.

All the Default setting is the recommended starting point of the sound. Turn down your audio system volume to prevent any damage.

And ALWAYS REMEMBER, this is a GUITAR PREAMP with no CABINET MODEL!

THE BEST OF IT → CRUNCH PASSION V.1 is totally free! Do not SHARE the plugin without this documentation/manual and Do not RESKIN/SELL the plugin. I would be appreciate if you give comment, critic and suggestions.

Big thanks to Christian Budde Analyzer, any digital recording forum, literature on internet and people who direct and indirect help me!

CRUNCH PASSION V.1 is design by ronaldpassion@yahoo.com,

1st Studio Medan, Sumatera Utara.

Peace from Indonesia!